

HDMI Grabber Type:

- 1. Standalone Mode (PC free) Storage: USB HDD/USB Flash Drive
- 2. Dual Mode (Standalone Mode + PC Mode) Storage: USB HDD/USB Flash Drive, SD Card or PC HDD

Safety Precautions

Before using the HDMI Grabber please ensure that you read and understand the safety precautions below.

Do not attempt to open the case of the HDMI Grabber or modify it in any way, as this will void the warranty.

Keep the HDMI Grabber away from heat source, sunlight, humid place & liquids.

The HDMI Grabber may become warm during usage. This does not indicate malfunction.

Do not place heavy objects on the HDMI Grabber, as this may cause the device to overheat and malfunction.

If the exterior of the HDMI Grabber requires cleaning, wipe it with a soft dry cloth.

Do not dispose of the device via conventional domestic waste.

Recording Steps

- 1. Switch on power, LED will flash quickly in blue and green.
- Connect video source to HDMI Grabber. LED will turn blue (1080i/p) or green (720p).
- 3. Connect a USB storage device to the USB port of HDMI Grabber.
- 4. Press REC / STOP button to start recording, the LED will flash slowly.
- 5. Press REC / STOP button again to stop recording.
- 6. The LED will flash in blue / green slowly. DO NOT remove USB device as the file is being saved. The LED goes off when file is saved.

Product Connectors/Buttons/LED Lights

No.	Standalone	Dual Mode
1	Power	Power
2	DC input 5V/2A	DC input 5V/2A
3	HDMIIN	HDMIIN
4	HDMI OUT	HDMI OUT
5	MIC input	MIC input
6	USB2.0	USB2.0
7		Mirco USB2.0 (USB to PC)
8	Record/Stop button	Record/Stop button



